



Installer and user reference guide

Madoka wired remote controller




Table of contents

1	About the documentation	5
1.1	About this document.....	5
1.2	Meaning of warnings and symbols	6
2	General safety precautions	7
2.1	For the installer	7
2.2	For the user	8
3	Specific installer safety instructions	9
For the user		10
4	Remote controller: Overview	11
4.1	Buttons	11
4.2	Status icons.....	11
4.3	Status indicator.....	12
5	Operation	14
5.1	Date and time	14
5.1.1	About date and time.....	14
5.1.2	To set date and time.....	14
5.2	Basic usage	15
5.2.1	Home screen.....	15
5.2.2	Main menu.....	16
5.3	Operation mode	17
5.3.1	About the operation modes.....	18
5.3.2	To set the operation mode.....	19
5.4	Setpoint	19
5.4.1	About the setpoint.....	19
5.4.2	To set the setpoint.....	21
5.5	Airflow	22
5.5.1	Airflow direction	22
5.5.2	Fan speed	23
5.6	Advanced usage.....	23
6	Maintenance and service	24
6.1	Overview: Maintenance and service.....	24
7	Troubleshooting	25
7.1	Overview: Troubleshooting.....	25
For the installer		26
8	About the box	27
8.1	To unpack the controller.....	27
9	Preparation	28
9.1	Wiring requirements	28
9.1.1	To prepare the wiring for installation	28
10	Installation	29
10.1	Overview: Installation.....	29
10.2	Mounting the controller.....	29
10.2.1	About mounting the controller	29
10.2.2	To mount the controller	30
10.3	Connecting the electrical wiring	31
10.3.1	Precautions when connecting the electrical wiring.....	31
10.3.2	To connect the electrical wiring	31
10.4	Closing the controller	32
10.4.1	To close the controller.....	32
10.5	Opening the controller.....	33
10.5.1	Precautions when opening the controller.....	33
10.5.2	To open the controller.....	33
11	Starting up the system	34

11.1	Controller designation.....	34
11.2	To designate a controller as slave.....	34
12	Remote controller: Overview	36
12.1	Buttons	36
12.2	Status icons.....	36
12.3	Status indicator.....	37
12.3.1	Behaviour	38
13	Operation	39
13.1	Basic usage	39
13.1.1	Screen backlight.....	39
13.1.2	Home screen	40
13.1.3	Information screen	40
13.1.4	Main menu.....	41
13.2	Operation mode	42
13.2.1	About the operation modes	43
13.2.2	To set the operation mode	44
13.3	Setpoint	45
13.3.1	About the setpoint	45
13.3.2	To set the setpoint.....	47
13.4	Date and time.....	47
13.4.1	About date and time	47
13.4.2	To set date and time	48
13.5	Airflow	48
13.5.1	Airflow direction	48
13.5.2	Fan speed	49
13.6	Advanced usage.....	50
14	Configuration	51
14.1	Installer menu.....	51
14.1.1	About the installer menu	51
14.1.2	Screen settings.....	52
14.1.3	Status indicator settings	53
14.1.4	Field settings.....	53
14.1.5	Miscellaneous settings.....	60
14.2	Software update	65
14.2.1	About software updates	65
14.2.2	Software update with app.....	65
14.2.3	Software update with updating tool	66
15	About the app	68
15.1	Operation and configuration overview.....	68
15.2	Pairing	68
15.2.1	About pairing	68
15.2.2	To pair the app with a controller.....	69
15.2.3	To make a Bluetooth connection	69
15.2.4	To terminate the Bluetooth connection	70
15.2.5	To remove bonding information	71
15.3	User access levels	71
15.3.1	About user access levels.....	71
15.3.2	Basic mode.....	71
15.3.3	Advanced mode	72
15.3.4	Installer mode	72
15.4	Demo mode.....	73
15.4.1	About demo mode.....	73
15.4.2	To launch demo mode.....	73
15.4.3	To exit demo mode.....	74
15.5	Functions	74
15.5.1	Overview: Functions	74
15.5.2	General.....	76
15.5.3	Remote controller settings.....	76
15.5.4	Energy saving	78
15.5.5	Scheduling.....	78
15.5.6	Configuration and operation	80
15.5.7	Maintenance.....	83
16	Maintenance	88
16.1	Maintenance safety precautions	88
16.2	About maintenance.....	88
16.3	To remove a warning screen.....	90

Table of contents

16.4	To clean the controller	90
16.5	Time to clean filter indication	90
16.5.1	To remove the Time to clean filter indication.....	90
17	Troubleshooting	91
17.1	Error codes of the indoor unit	91
18	Technical data	92
18.1	Connection diagram	92
18.1.1	Typical layout	92
18.1.2	Typical layout for group control	92
18.1.3	Controller + DIII central control equipment.....	93
19	Glossary	94

1 About the documentation

1.1 About this document

Target audience

Authorised installers + end users

Documentation set

This document is part of a documentation set. The complete set consists of:

- **Installation and operation manual:**
 - Installation instructions
 - Basic operation instructions
- **Installer and user reference guide:**
 - Extended installation and operation information
- **Declaration of conformity:**



INFORMATION: Declaration of conformity

Hereby, Daikin Europe N.V. declares that the radio equipment type BRC1H is in compliance with the Directive 2014/53/EU. The original declaration of conformity is available from the BRC1H product pages.

The documentation set is available from the BRC1HF product pages.

BRC1HF



<https://qr.daikin.eu/?N=BRC1HF>



INFORMATION: Madoka Assistant in-app documentation

The controller only allows for basic settings and operation. Advanced settings and operation are performed via the Madoka Assistant app. For more information, see the app and its in-app documentation. The Madoka Assistant app is available from Google Play and the Apple Store.

The latest revision of the supplied documentation is published on the regional Daikin website and is available via your dealer.

The original instructions are written in English. All other languages are translations of the original instructions.

1.2 Meaning of warnings and symbols



DANGER

Indicates a situation that results in death or serious injury.



DANGER: RISK OF ELECTROCUTION

Indicates a situation that could result in electrocution.



WARNING

Indicates a situation that could result in death or serious injury.



CAUTION

Indicates a situation that could result in minor or moderate injury.



NOTICE

Indicates a situation that could result in equipment or property damage.



INFORMATION

Indicates useful tips or additional information.



DANGER: RISK OF EXPLOSION

Indicates a situation that could result in explosion.

2 General safety precautions

In this chapter

2.1	For the installer.....	7
2.2	For the user.....	8

2.1 For the installer

The precautions described in this document cover very important topics, follow them carefully.



INFORMATION

This controller is an option and cannot be used standalone. Also see the installation and operation manual of the indoor and outdoor units.



WARNING

Improper installation or attachment of equipment or accessories could result in electrical shock, short-circuit, leaks, fire or other damage to the equipment. ONLY use accessories, optional equipment and spare parts made or approved by Daikin unless otherwise specified.



WARNING

All field wiring and components MUST be installed by a licensed electrician and MUST comply with the applicable legislation.



NOTICE

The remote controller MUST be mounted indoors.



NOTICE

When the controller is used as room thermostat, select an installation location where the average temperature in the room can be detected.

Do NOT install the controller in the following places:

- In places where it is exposed to direct sunlight.
- In places where it is near a heat source.
- In places that are affected by outside air or air draught due to e.g. door opening/closing.
- In places where the display can easily get dirty.
- In places where there is NO easy access to the controls.
- In places with temperatures $<-10^{\circ}\text{C}$ and $>50^{\circ}\text{C}$.
- In places where the relative humidity is $>95\%$.
- In places where there is machinery that emits electromagnetic waves. Electromagnetic waves may disturb the control system, and cause malfunction of the equipment.
- In places where it may be exposed to water, or in generally moist areas.

If you are NOT sure how to install or operate the unit, contact your dealer.

After finishing installation:

- Conduct a trial operation to check for faults.
- Explain the user how to operate the controller.
- Ask the user to store the manual for future reference.



INFORMATION

Consult your dealer regarding the relocation and reinstallation of the controller.

2.2 For the user

General



WARNING

To clean the controller, do NOT use organic solvents, such as paint thinner.



WARNING

Do NOT use flammable materials (e.g. hairspray or insecticide) near the controller.



WARNING

To prevent electric shocks or fire:

- Do NOT operate the controller with wet hands.
- Do NOT disassemble the controller and touch interior parts. Contact your dealer.
- Do NOT modify or repair the controller. Contact your dealer.
- Do NOT relocate or reinstall the controller by yourself. Contact your dealer.



WARNING

Do NOT play with the unit or its remote controller. Accidental operation by a child may result in impairment of bodily functions and harm health.

3 Specific installer safety instructions

Always observe the following safety instructions and regulations.



CAUTION

NEVER touch the internal parts of the controller.



CAUTION

When closing the controller, be careful not to pinch the wiring.



CAUTION

Before starting up the system, make sure:

- The indoor and outdoor unit wiring is completed.
- The switch box covers of the indoor and outdoor units are closed.



CAUTION

When connecting the controller to the indoor unit, make sure the indoor unit switchbox and transmission wiring are not connected.



WARNING

All field wiring and components **MUST** be installed by a licensed electrician and **MUST** comply with the applicable legislation.



WARNING

Before carrying out any maintenance or repair activities, stop system operation with the controller, and turn off the power supply circuit breaker. **Possible consequence:** electrical shock or injury.



WARNING

Do **NOT** wash the remote controller. **Possible consequence:** electric leakage, electrical shock, or fire.


For the user

4 Remote controller: Overview

In this chapter

4.1	Buttons.....	11
4.2	Status icons.....	11
4.3	Status indicator.....	12

4.1 Buttons



- a  ON/OFF
 - When OFF, press to turn ON the system.
 - When ON, press to turn OFF the system.
- b  ENTER/ACTIVATE /SET
 - From the home screen, enter the main menu.
 - From the main menu, enter one of the submenus.
 - From their respective submenu, activate an operation mode.
 - In one of the submenus, confirm a setting.
- c  CYCLE/ADJUST
 - Cycle left.
 - Adjust a setting (default: decrease).
- d  CYCLE/ADJUST
 - Cycle right.
 - Adjust a setting (default: increase).

4.2 Status icons

Icon	Description
	System operation ON. Indicates that the system is in operation.
	System operation OFF. Indicates that the system is NOT in operation.
	Bluetooth. ⁽¹⁾ Indicates that the controller is communicating with a mobile device, for use with the Madoka Assistant app.

⁽¹⁾ The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and use of such marks by Daikin Europe N.V. is under license. Other trademarks and trade names are those of their respective owners.


Icon	Description
	Lock. Indicates that a function or operation mode is locked and therefore cannot be used or selected.
	Centralised control. Indicates that the system is controlled by central control equipment (optional accessory) and that control of the system by the controller is limited.
	Changeover under centralised control. Indicates that the cooling/heating changeover is under centralised control by another indoor unit, or by an optional cool/ heat selector that is connected to the outdoor unit.
	Schedule/Timer. Indicates that the system operates according to a schedule, or that the OFF timer is enabled.
	Time not set. Indicates that controller's time is not set.
	Test operation. Indicates that test operation mode is active.
	Inspection. Indicates that the indoor or outdoor unit is being inspected.
	Periodic inspection. Indicates that the indoor or outdoor unit is being inspected.
	Backup. Indicates that in the system an indoor unit is set as backup indoor unit.
	Information. Indicates that the system has a message to convey. To see the message, go to the information screen.
	Warning. Indicates that an error occurred, or that an indoor unit component needs to be maintained. For more information about troubleshooting error codes, see the installer and user reference guide.
	Setback. Indicates that the indoor unit is operating under setback conditions.



INFORMATION

- For information on the operation mode icons, see "[5.3 Operation mode](#)" [▶ 17].
- Most icons are related to things set in the Madoka Assistant app. For more information, see the app, and the installer and user reference guide.

4.3 Status indicator



a

- a Status indicator

5 Operation

In this chapter

5.1	Date and time	14
5.1.1	About date and time	14
5.1.2	To set date and time	14
5.2	Basic usage.....	15
5.2.1	Home screen	15
5.2.2	Main menu	16
5.3	Operation mode	17
5.3.1	About the operation modes	18
5.3.2	To set the operation mode	19
5.4	Setpoint.....	19
5.4.1	About the setpoint	19
5.4.2	To set the setpoint	21
5.5	Airflow.....	22
5.5.1	Airflow direction.....	22
5.5.2	Fan speed	23
5.6	Advanced usage.....	23

5.1 Date and time

Set the date and time for the indoor units connected to the controller.

5.1.1 About date and time


Depending on daylight saving time settings, the date and time menu has the following daylight saving time indicators:

	Summer time
	Winter time


For more information, see "[Indoor unit field settings](#)" [[▶ 57](#)] (remote controller settings) and "[Date and time](#)" [[▶ 78](#)] (app settings).

5.1.2 To set date and time

- 1 Navigate to the date and time menu.



- 2 Press **+** to activate .



Result: The fields become editable.



- 3 Set the date and time. Set with **←** and **→**. Confirm with **⏹**. Cycle through the menu until all fields are set correctly.

Result: You set the date and the time.



INFORMATION

Confirming the value in a field will automatically bring you to the next field. To finish making settings and leave the menu, navigate to and confirm the value in the last field.

5.2 Basic usage

5.2.1 Home screen

Home screen mode

Depending on configuration, the controller either has a standard or a detailed home screen. While the standard home screen gives you only limited information, the detailed home screen gives you additional through status icons. After a period of operation inactivity, the controller will always revert to the home screen.

Standard	Detailed

When the Home screen mode is Detailed, the indoor temperature is displayed in addition to the setpoint temperature.



INFORMATION

The remote controller does NOT display negative indoor temperature values. When the indoor temperature is below 0°C, then the remote controller displays 0°C instead. In this case, the Madoka Assistant app also does not display any indoor temperature value.

Home screen operation

In certain conditions, the controller allows you to perform actions from the home screen.

Condition	Action
The system is running in Cooling, Heating, or Auto operation mode.	Change the setpoint



INFORMATION

- Depending on configuration, the home screen displays the setpoint either as a numerical value, or as a symbol. For more information, see "5.4.1 About the setpoint" [▶ 19].
- In case the home screen displays the setpoint as a symbol, then it will only display the status icons of the standard home screen mode, even when the controller is in detailed home screen mode.



INFORMATION

The controller is equipped with a power saving function that causes the screen to go blank after a period of inactivity. To make the screen light up again, press any button.

5.2.2 Main menu

From the home screen, press to enter the main menu. Use and to cycle through the menus. Press again to enter one of the menus.

Menu	Description
	Operation mode. Set the operation mode. Note: the operation mode menu is locked by default. To access the menu and set the operation mode, release the function lock first. For more information, see "Function lock" [▶ 81].
	Date and time. Make date and time settings.
	Airflow direction. Set the indoor unit airflow direction.
	Fan speed. Set the indoor unit fan speed.
	Bluetooth. Activate Bluetooth to control the system with the Madoka Assistant app, and/or to perform a remote controller software update.



INFORMATION

- Depending on the type of indoor unit you are operating, more or less menus may be available.
- In the main menu, the icon for each menu reflects the current active setting or mode. When operating the controller, the menu you navigate through can look different from that represented in this manual.
- The controller only allows for basic operation of the system. For advanced operation (setback, schedule timer, ...), see the Madoka Assistant app.

**INFORMATION**

It is possible that menus are locked. When this is the case, they appear crossed-out in the main menu, and get accompanied by a lock icon. The locking of functions happens through the Madoka Assistant app. For more information, see the Madoka Assistant app and "[Function lock](#)" [▶ 81].



5.3 Operation mode

**INFORMATION**

Depending on the indoor unit, more or less operation modes are available.

**INFORMATION**

The operation mode menu is locked by default. The menu appears crossed-out in the main menu, and is accompanied by a lock icon. To access the operation mode menu and change the operation mode, the function lock must first be released. The locking and releasing of functions happens through the Madoka Assistant app. For more information, see "[Function lock](#)" [▶ 81] and the Madoka Assistant app.



The indoor unit can operate in various operation modes.

Icon	Operation mode
	Cooling. In this mode, cooling will be activated as required by the setpoint, or by Setback operation.
	Heating. In this mode, heating will be activated as required by the setpoint, or by Setback operation.
	Fan Only. In this mode, air circulates without heating or cooling.
	Auto. In Auto mode, the indoor unit automatically switches between heating and cooling mode, as required by the setpoint.

**INFORMATION**

After changing the operation mode from Heating or Cooling to Auto, allow up to 10 minutes for the indoor unit to automatically determine whether it needs to operate in heating or cooling mode. During this time, the operation mode stays as the operation mode that was active before Auto was selected.

5.3.1 About the operation modes

**INFORMATION**

If the indoor unit is a cooling-only model, it can only be set to run in Cooling or Fan only operation mode.

**INFORMATION**

When operation modes are not available in the operation mode menu, it is additionally possible that they are locked. The locking of operation modes occurs through the Madoka Assistant app. For more information, see the Madoka Assistant app and "[Function lock](#)" [▶ 81].

**INFORMATION**

If the operation mode changeover of an indoor unit is under centralised control ('changeover under centralised control' status icon blinking in the home screen), then it is NOT possible to change the operation mode of that indoor unit. For more information, see "[Cooling/Heating masterhood](#)" [▶ 62].

Cooling

If the outdoor air temperature is high, it can take some time until the indoor room temperature reaches the setpoint temperature.

The indoor unit can run in Cooling operation mode because it is operating under Setback conditions. For more information, see "[Setback](#)" [▶ 80].

Heating

When running in Heating operation mode, the system requires a longer time to reach the setpoint temperature than when running in Cooling operation mode. To make up for this, it is recommended to let the system start operation in advance by making use of the timer function.

The indoor unit can run in Heating operation mode because it is operating under Setback conditions. For more information, see "[Setback](#)" [▶ 80].

**INFORMATION**

When the system is stopped while the indoor unit is running in Heating operation mode, the fan will continue to operate for approximately 1 minute, this to get out any heat remaining in the indoor unit.

**INFORMATION**

- The lower the outdoor air temperature, the lower the heating capacity. If the system's heating capacity is insufficient, it is recommended to include another heating appliance into the setup (if you use a combustion appliance, ventilate the room regularly. Also, do not use the heating appliance in places where it is exposed to the airflow of the indoor unit).
- The indoor unit is of the hot air circulation type. As a result, after operation start, it takes the indoor unit some time to warm up the room.
- The indoor unit fan will automatically operate until the indoor temperature of the system rises to a certain level.
- When hot air stays under the ceiling and your feet feel cold, it is recommended to include a circulator into the setup.

Auto

The indoor unit automatically switches between heating and cooling mode, as required by the setpoint. The changeover from the one operation mode to the other is based on the indoor unit setpoint logic.



INFORMATION

After changing the operation mode from Heating or Cooling to Auto, allow up to 10 minutes for the indoor unit to automatically determine whether it needs to operate in heating or cooling mode. During this time, the operation mode stays as the operation mode that was active before Auto was selected.



INFORMATION

Indoor unit field setting 1c-02 allows for changes to the behaviour of heating/cooling icons during Auto operation (display or do not display in addition to the Auto icon). For more information, see "[Indoor unit field settings](#)" [▶ 57].

Fan only

During Fan only operation, the indoor unit circulates air without heating or cooling.


5.3.2 To set the operation mode

Prerequisite: The operation mode menu function lock is released.

- 1 Navigate to the operation mode menu.



- 2 Use and to select an operation mode.



- 3 Press to activate.

Result: The indoor unit changes its operation mode and the controller returns to the home screen.

For more information about releasing the operation mode menu function lock, see "[Function lock](#)" [▶ 81].

5.4 Setpoint

The setpoint is the target temperature for the Cooling, Heating, and Auto operation modes.

5.4.1 About the setpoint

Depending on configuration, the home screen displays the temperature setpoint either as a numerical value, or as a symbol.

**INFORMATION**

For how to set the home screen setpoint, see the Madoka Assistant app. Also see "Screen" [▶ 76].

Home screen setpoint: Numerical


In case the home screen displays the temperature setpoint as a numerical value, you control the room temperature by raising or lowering the setpoint by 1°C increments.



The default setpoint range is 16°C~32°C. If any limitations are set to this range with the setpoint range function (Madoka Assistant app function; see "Setpoint range" [▶ 81]), it is only possible to raise or lower the setpoint up/down to the set maximum/minimum setpoint range limits.


Home screen setpoint: Symbolic

In case the home screen displays the temperature setpoint as a symbol, you control the room temperature by raising or lowering the setpoint in relation to the "reference setpoint" (visually indicated by the marker in the middle of the thermometer).



It is possible to raise the setpoint up to three steps of 1°C above and up to three steps of 1°C below the reference setpoint.

Example: if the reference setpoint is 25°C, it is possible to raise the setpoint to 28°C and lower it to 22°C.

**INFORMATION**

For how to set the reference setpoint, see the Madoka Assistant app. Also see "Screen" [▶ 76].


Exceptions to this logic are possible in case of:

- Setpoint range limitations
- Central control / control by a schedule

Setpoint range



If any limitations are set to the default setpoint range (16°C~32°C) with the setpoint range function (Madoka Assistant app function; see "Setpoint range" [▶ 81]), it is only possible to raise or lower the setpoint up/down to the set upper/lower setpoint range limits.

Example: if the reference temperature is 25°C, you can normally lower the setpoint three steps to 22°C. However, if a setpoint range limit is set to 23°C, you can only lower the setpoint to 23°C.



Central control / Schedule

If the system is under the control of a centralised controller or a schedule, then the regular +3°C/-3°C setpoint range limits can get overruled AND changed.

IF	THEN
The centralised controller or schedule imposes a setpoint that is within the regular +3°C/-3°C setpoint range.	Nothing unusual happens and the system follows the regular setpoint and setpoint range logic.
The centralised controller or schedule imposes a setpoint that exceeds the regular +3°C/-3°C setpoint range.	<p>The imposed setpoint becomes the new upper/lower limit of the +3°C/-3°C range, and the whole range shifts in relation to this new limit.</p> <p>Example: the reference setpoint is set to 25°C, yielding the following setpoint range:</p>  <p>If the centralised controller or schedule changes the setpoint to 21°C, which is below the range, then "21°C" becomes the new lower limit, and the range shifts in relation to this new limit.</p> 

5.4.2 To set the setpoint

Prerequisite: The active operation mode is either 'Cooling', 'Heating', or 'Auto'.

- 1 In the home screen, use  and  to adjust the setpoint.



Result: The indoor unit changes its temperature setpoint.

5.5 Airflow

5.5.1 Airflow direction

The airflow direction is the direction in which the indoor unit blows its air.

About airflow direction

The following airflow directions can be set:

Direction	Screen
Fixed position. The indoor unit blows air in 1 of 5 fixed positions.	
Swing. The indoor unit alternates between the 5 positions.	
Auto. The indoor unit adjusts its airflow direction according to movement sensed by a movement sensor.	



INFORMATION

- Depending on the type of indoor unit, and/or on system layout and organisation, Auto airflow direction may not be available.
- For some types of indoor unit, you cannot set the airflow direction.

Automatic airflow control

In the following operating conditions, the airflow direction of the indoor units is controlled automatically:

- When the room temperature is higher than the controller's setpoint for Heating operation (including Auto operation).

To set the airflow direction

- 1 Navigate to the airflow direction menu.



- 2 Use and to adjust the airflow direction.



- 3 Press  to confirm.

Result: The indoor unit changes its airflow direction and the controller returns to the home screen.

5.5.2 Fan speed

The fan speed is the strength of the airflow coming out of the indoor unit.

About fan speed

Depending on the indoor unit, you can choose between either:



INFORMATION

- For mechanical protection purposes, it is possible that the indoor unit switches itself to 'Automatic fan speed' mode.
- If the fan stops operating, this does not necessarily mean system failure. The fan can stop operating at all times.
- It may take some time before changes made to fan speed settings are actually carried out.

To set the fan speed

- 1 Navigate to the fan speed menu.



- 2 Use  and  to adjust the fan speed.



- 3 Press  to confirm.

Result: The indoor unit changes its fan speed and the controller returns to the home screen.

5.6 Advanced usage

The controller only allows for basic operation. For advanced operation, use the Madoka Assistant app.



INFORMATION



To operate the controller with the app, you need to connect the controller to a mobile device on which the app is installed. For instructions, see ["15.2 Pairing" \[p. 68\]](#).

6 Maintenance and service

6.1 Overview: Maintenance and service

When a system components needs maintenance or service, consult your dealer. To indicate that maintenance is due, the controller displays  on the home screen, and/or displays a warning screen as soon as you press  to enter the main menu from the home screen.


The following warning screens are related to indoor unit maintenance:

<p>Clean the indoor unit filter</p> 	<p>Replace the indoor unit filter</p> 
<p>Empty the indoor unit dustbox</p> 	<p>—</p>

7 Troubleshooting

7.1 Overview: Troubleshooting

When the system is in error, consult your dealer. To indicate system error, the controller displays  on the home screen, and/or displays an error screen as soon as you press  to enter the main menu from the home screen.




For the installer

8 About the box

8.1 To unpack the controller

- 1 Open the box.
- 2 Separate the accessories.



- a** Installation and operation manual
b Wood screws + wall plugs (Ø4.0×30)

9 Preparation


9.1 Wiring requirements

All wiring must comply with the following requirements:

Wire specification	Value
Type	Sheathed vinyl cord or cable (2 wires)
Section	0.75~1.25 mm ²
Maximum length	500 m

9.1.1 To prepare the wiring for installation

- 1 Peel the sheath of the part of the cable that needs to pass through the inside of the rear casing (L), according to the figure and the table.
- 2 Keep a 10 mm distance between the length of the 2 wires.



Wiring outlet	L
Top	±150 mm
Left	±120 mm
Bottom	±100 mm
Rear	No requirements

10 Installation



NOTICE

During the installation of the controller, keep the installation environment dust-free in order to avoid any particles entering the PCB side of the controller.

In this chapter

10.1	Overview: Installation	29
10.2	Mounting the controller	29
10.2.1	About mounting the controller	29
10.2.2	To mount the controller	30
10.3	Connecting the electrical wiring	31
10.3.1	Precautions when connecting the electrical wiring	31
10.3.2	To connect the electrical wiring	31
10.4	Closing the controller	32
10.4.1	To close the controller	32
10.5	Opening the controller	33
10.5.1	Precautions when opening the controller	33
10.5.2	To open the controller	33

10.1 Overview: Installation

The installation of the controller typically consists of the following stages:


- 1 Determining how you want to route the electrical wiring, and nipping away a piece of the rear casing accordingly.
- 2 Mounting the rear casing to the wall.
- 3 Connecting the electrical wiring.
- 4 Closing the controller.

10.2 Mounting the controller

10.2.1 About mounting the controller

Before you can mount the controller, you have to determine the wiring routing, and accordingly, remove a piece of the controller's rear casing.

The wiring can be routed from the top, the rear, the left, or the bottom. Remove a piece of the rear casing according to the illustration:



- a Wiring from the top
- b Wiring from the left
- c Wiring from the bottom

In case you are routing the wiring from the rear, you do not have to remove anything.




INFORMATION

When routing the wiring from the top or from the rear, insert the wiring through the knockout hole before mounting the rear casing to the wall.


10.2.2 To mount the controller

- 1 Take the screws and plugs from the accessory bag.
- 2 Mount the rear casing to a flat surface.



INFORMATION

If required (e.g. when mounting to a flush-mounted electrical installation box), mount the rear casing by way of the knockout holes.



NOTICE

When mounting the rear casing to a flush-mounted electrical installation box inside a wall, make sure that that wall is completely flat.



NOTICE

Be careful not to deform the rear casing by overtightening the mounting screws.

10.3 Connecting the electrical wiring

10.3.1 Precautions when connecting the electrical wiring



INFORMATION

Also read the precautions and requirements in the following chapters:

- General safety precautions
- Preparation



WARNING

All field wiring and components **MUST** be installed by a licensed electrician and **MUST** comply with the applicable legislation.



CAUTION

When connecting the controller to the indoor unit, make sure the indoor unit switchbox and transmission wiring are not connected.



NOTICE

The wiring for connection is **NOT** included.



NOTICE

When wiring, run the wiring away from the power supply wiring in order to avoid receiving electric noise (external noise).




INFORMATION




P1 and P2 have no polarity.

10.3.2 To connect the electrical wiring

Connect controller terminals P1/P2 to indoor unit terminals P1/P2.

From the top



From the rear**From the left****From the bottom**

10.4 Closing the controller

**CAUTION**

NEVER touch the internal parts of the controller.

**CAUTION**


When closing the controller, be careful not to pinch the wiring.

**NOTICE**

To prevent damage, make sure the front of the controller is clicked into the rear casing securely.

10.4.1 To close the controller

- 1 Click the front of the controller into the rear casing.



- 2 When the installation site is dust-free, peel off the protective seal.

10.5 Opening the controller

10.5.1 Precautions when opening the controller

**NOTICE**

The controller PCB is mounted into the front casing. When opening the controller, be careful not to damage the PCB.

**NOTICE**

When the front and rear casing are separated, make sure the PCB does not come into contact with dust or moisture.

10.5.2 To open the controller

11 Starting up the system



CAUTION

Before starting up the system, make sure:

- The indoor unit wiring is completed.
- The switch box covers of the indoor units are closed.

The controller gets its power from the indoor unit. It will start up as soon as it is connected. For the controller to be operable, make sure the indoor unit is powered on.

Once the controller is powered, it will automatically start up. If it is the first and only controller that is connected to the indoor unit, it will automatically get designated as a master controller.

11.1 Controller designation

On the information screen, master/slave status is indicated by the following icons:

Icon	Description
	Master
	Slave

For more information, see "[13.1.3 Information screen](#)" [▶ 40].



INFORMATION

If the slave controller does not display the home screen two minutes after its designation, turn off the power and check the wiring.



INFORMATION

After re-designating a controller, the system requires a power reset.



INFORMATION

Slave controllers do not support all functions. If you cannot find a function on a slave controller, check for it on the master controller.



INFORMATION

For master and slave controllers to function together, they need to have the same value for the "Home screen setpoint" setting (Madoka Assistant app setting), i.e. all set to "Numerical" or all set to "Symbolic".

11.2 To designate a controller as slave

Prerequisite: A master controller is already connected to the indoor unit.


- 1 Connect a second controller.

Result: It will start up automatically.

- 2 Wait for a U5 or U8 error to appear on the screen.



- 3 When the U5 or U8 error appears, press  and keep it pressed until "2" appears on the screen.




Result: The controller is now designated as slave.

12 Remote controller: Overview

In this chapter

12.1	Buttons.....	36
12.2	Status icons.....	36
12.3	Status indicator.....	37
12.3.1	Behaviour.....	38

12.1 Buttons



- a ON/OFF
 - When OFF, press to turn ON the system.
 - When ON, press to turn OFF the system.
- b ENTER/ACTIVATE /SET
 - From the home screen, enter the main menu.
 - From the main menu, enter one of the submenus.
 - From their respective submenu, activate an operation mode.
 - In one of the submenus, confirm a setting.
- c CYCLE/ADJUST
 - Cycle left.
 - Adjust a setting (default: decrease).
- d CYCLE/ADJUST
 - Cycle right.
 - Adjust a setting (default: increase).

12.2 Status icons

Icon	Description
	System operation ON. Indicates that the system is in operation.
	System operation OFF. Indicates that the system is NOT in operation.
	Bluetooth. ⁽¹⁾ Indicates that the controller is communicating with a mobile device, for use with the Madoka Assistant app.

⁽¹⁾ The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and use of such marks by Daikin Europe N.V. is under license. Other trademarks and trade names are those of their respective owners.


Icon	Description
	Lock. Indicates that a function or operation mode is locked and therefore cannot be used or selected.
	Centralised control. Indicates that the system is controlled by central control equipment (optional accessory) and that control of the system by the controller is limited.
	Changeover under centralised control. Indicates that the cooling/heating changeover is under centralised control by another indoor unit, or by an optional cool/ heat selector that is connected to the outdoor unit.
	Schedule/Timer. Indicates that the system operates according to a schedule, or that the OFF timer is enabled.
	Time not set. Indicates that controller's time is not set.
	Test operation. Indicates that test operation mode is active.
	Inspection. Indicates that the indoor or outdoor unit is being inspected.
	Periodic inspection. Indicates that the indoor or outdoor unit is being inspected.
	Backup. Indicates that in the system an indoor unit is set as backup indoor unit.
	Information. Indicates that the system has a message to convey. To see the message, go to the information screen.
	Warning. Indicates that an error occurred, or that an indoor unit component needs to be maintained. For more information about troubleshooting error codes, see the installer and user reference guide.
	Setback. Indicates that the indoor unit is operating under setback conditions.



INFORMATION

- For information on the operation mode icons, see "[13.2 Operation mode](#)" [▶ 42].
- Most icons are related to things set in the Madoka Assistant app. For more information, see the app, and the installer and user reference guide.

12.3 Status indicator



a

a Status indicator

12.3.1 Behaviour

The behaviour of the status indicator depends on remote controller field setting R1-11 (status indicator mode). Depending on the value that is set for this setting, the status indicator has the following behaviour:

Operation state	Status indicator behaviour		
	0 (Normal)	1 (Hotel setting 1)	2 (Hotel setting 2)
Operation ON	ON	ON	ON (when the backlight goes into faint state, the status indicator turns OFF)
Operation OFF	OFF	OFF	OFF
Error	Blinking	(no change)	(no change)
Warning	ON	ON	ON (when the backlight goes into faint state, the status indicator turns OFF)
Setting of status indicator intensity	ON	ON	ON
Pairing with indoor unit	Blinking	Blinking	Blinking

**INFORMATION**

Remote controller field setting R1-11 allows for changes to the behaviour of the status indicator, making the controller suitable for use in hotels.

13 Operation

In this chapter

13.1	Basic usage.....	39
13.1.1	Screen backlight	39
13.1.2	Home screen	40
13.1.3	Information screen.....	40
13.1.4	Main menu	41
13.2	Operation mode	42
13.2.1	About the operation modes	43
13.2.2	To set the operation mode	44
13.3	Setpoint.....	45
13.3.1	About the setpoint.....	45
13.3.2	To set the setpoint	47
13.4	Date and time	47
13.4.1	About date and time	47
13.4.2	To set date and time	48
13.5	Airflow.....	48
13.5.1	Airflow direction.....	48
13.5.2	Fan speed	49
13.6	Advanced usage.....	50

13.1 Basic usage

13.1.1 Screen backlight

For the controller to be operable, the screen backlight needs to be ON. Otherwise, the controller does not detect any button presses.

After a period of operation inactivity, the backlight will either turn OFF, or go into a faint ON state, depending on operation conditions:

- Operation OFF: backlight OFF;
- Operation ON: backlight ON faintly.




INFORMATION

- Backlight state changeover after inactivity is set with remote controller field setting R1-8 (No-operation timer). For more information, see "[Remote controller field settings](#)" [▶ 58].
- Backlight faintness is set with remote controller field setting R1-10 (Backlight faintness). For more information, see "[Remote controller field settings](#)" [▶ 58].
- For instructions on how to set screen brightness and contrast when the backlight is ON, see "[14.1.2 Screen settings](#)" [▶ 52].

To turn ON the backlight

- 1 Press  shortly.



13.1.2 Home screen

Home screen mode

Depending on configuration, the controller either has a standard or a detailed home screen. While the standard home screen gives you only limited information, the detailed home screen gives you additional through status icons. After a period of operation inactivity, the controller will always revert to the home screen.


Standard	Detailed
	

When the Home screen mode is Detailed, the indoor temperature is displayed in addition to the setpoint temperature.

i **INFORMATION**
 The remote controller does NOT display negative indoor temperature values. When the indoor temperature is below 0°C, then the remote controller displays 0°C instead. In this case, the Madoka Assistant app also does not display any indoor temperature value.

Home screen operation

In certain conditions, the controller allows you to perform actions from the home screen.

Condition	Action
The system is running in Cooling, Heating, or Auto operation mode.	Change the setpoint 

i **INFORMATION**

- Depending on configuration, the home screen displays the setpoint either as a numerical value, or as a symbol. For more information, see "[13.3.1 About the setpoint](#)" [▶ 45].
- In case the home screen displays the setpoint as a symbol, then it will only display the status icons of the standard home screen mode, even when the controller is in detailed home screen mode.

i **INFORMATION**
 The controller is equipped with a power saving function that causes the screen to go blank after a period of inactivity. To make the screen light up again, press any button.

13.1.3 Information screen

The controller collects operation information in an information screen.




When there is information to convey, the controller displays **i** in the top left corner of the home screen.



a **i**

On the information screen, you can find the following information:

<p>Status icons</p> 
<p>For the meaning of the status icons, see "12.2 Status icons" [▶ 36].</p>
<p>Software version</p>  <p>a Software version</p>
<p><i>i</i> INFORMATION</p> <ul style="list-style-type: none"> ▪ The presence of icons on the information screen depends on operation status. The controller may display more or less icons than are indicated here. ▪ The information screen always displays the current software version, regardless of operation status.

To enter the information screen

Prerequisite: The controller displays the home screen.

- 1 Press **○** and keep it pressed until the information screen appears.



13.1.4 Main menu

From the home screen, press **○** to enter the main menu. Use **←** and **→** to cycle through the menus. Press **○** again to enter one of the menus.


Menu	Description
	Operation mode. Set the operation mode. Note: the operation mode menu is locked by default. To access the menu and set the operation mode, release the function lock first. For more information, see " Function lock " [▶ 81].
	Date and time. Make date and time settings.
	Airflow direction. Set the indoor unit airflow direction.
	Fan speed. Set the indoor unit fan speed.
	Bluetooth. Activate Bluetooth to control the system with the Madoka Assistant app, and/or to perform a remote controller software update.

**INFORMATION**

- Depending on the type of indoor unit you are operating, more or less menus may be available.
- In the main menu, the icon for each menu reflects the current active setting or mode. When operating the controller, the menu you navigate through can look different from that represented in this manual.
- The controller only allows for basic operation of the system. For advanced operation (setback, schedule timer, ...), see the Madoka Assistant app.

**INFORMATION**

It is possible that menus are locked. When this is the case, they appear crossed-out in the main menu, and get accompanied by a lock icon. The locking of functions happens through the Madoka Assistant app. For more information, see the Madoka Assistant app and "[Function lock](#)" [▶ 81].




13.2 Operation mode

**INFORMATION**

Depending on the indoor unit, more or less operation modes are available.

**INFORMATION**

The operation mode menu is locked by default. The menu appears crossed-out in the main menu, and is accompanied by a lock icon. To access the operation mode menu and change the operation mode, the function lock must first be released. The locking and releasing of functions happens through the Madoka Assistant app. For more information, see ["Function lock" \[▶ 81\]](#) and the Madoka Assistant app.



The indoor unit can operate in various operation modes.

Icon	Operation mode
	Cooling. In this mode, cooling will be activated as required by the setpoint, or by Setback operation.
	Heating. In this mode, heating will be activated as required by the setpoint, or by Setback operation.
	Fan Only. In this mode, air circulates without heating or cooling.
	Auto. In Auto mode, the indoor unit automatically switches between heating and cooling mode, as required by the setpoint.

**INFORMATION**

After changing the operation mode from Heating or Cooling to Auto, allow up to 10 minutes for the indoor unit to automatically determine whether it needs to operate in heating or cooling mode. During this time, the operation mode stays as the operation mode that was active before Auto was selected.

13.2.1 About the operation modes

**INFORMATION**

If the indoor unit is a cooling-only model, it can only be set to run in Cooling or Fan only operation mode.

**INFORMATION**

When operation modes are not available in the operation mode menu, it is additionally possible that they are locked. The locking of operation modes occurs through the Madoka Assistant app. For more information, see the Madoka Assistant app and ["Function lock" \[▶ 81\]](#).

**INFORMATION**

If the operation mode changeover of an indoor unit is under centralised control ('changeover under centralised control' status icon blinking in the home screen), then it is NOT possible to change the operation mode of that indoor unit. For more information, see ["Cooling/Heating masterhood" \[▶ 62\]](#).

Cooling

If the outdoor air temperature is high, it can take some time until the indoor room temperature reaches the setpoint temperature.

The indoor unit can run in Cooling operation mode because it is operating under Setback conditions. For more information, see "[Setback](#)" [▶ 80].

Heating

When running in Heating operation mode, the system requires a longer time to reach the setpoint temperature than when running in Cooling operation mode. To make up for this, it is recommended to let the system start operation in advance by making use of the timer function.

The indoor unit can run in Heating operation mode because it is operating under Setback conditions. For more information, see "[Setback](#)" [▶ 80].



INFORMATION

When the system is stopped while the indoor unit is running in Heating operation mode, the fan will continue to operate for approximately 1 minute, this to get out any heat remaining in the indoor unit.



INFORMATION

- The lower the outdoor air temperature, the lower the heating capacity. If the system's heating capacity is insufficient, it is recommended to include another heating appliance into the setup (if you use a combustion appliance, ventilate the room regularly. Also, do not use the heating appliance in places where it is exposed to the airflow of the indoor unit).
- The indoor unit is of the hot air circulation type. As a result, after operation start, it takes the indoor unit some time to warm up the room.
- The indoor unit fan will automatically operate until the indoor temperature of the system rises to a certain level.
- When hot air stays under the ceiling and your feet feel cold, it is recommended to include a circulator into the setup.

Auto

The indoor unit automatically switches between heating and cooling mode, as required by the setpoint. The changeover from the one operation mode to the other is based on the indoor unit setpoint logic.



INFORMATION

After changing the operation mode from Heating or Cooling to Auto, allow up to 10 minutes for the indoor unit to automatically determine whether it needs to operate in heating or cooling mode. During this time, the operation mode stays as the operation mode that was active before Auto was selected.



INFORMATION

Indoor unit field setting 1c-02 allows for changes to the behaviour of heating/cooling icons during Auto operation (display or do not display in addition to the Auto icon). For more information, see "[Indoor unit field settings](#)" [▶ 57].

Fan only

During Fan only operation, the indoor unit circulates air without heating or cooling.

13.2.2 To set the operation mode

Prerequisite: The operation mode menu function lock is released.

- 1 Navigate to the operation mode menu.



- 2 Use  and  to select an operation mode.



- 3 Press  to activate.

Result: The indoor unit changes its operation mode and the controller returns to the home screen.

For more information about releasing the operation mode menu function lock, see ["Function lock" \[▶ 81\]](#).

13.3 Setpoint

The setpoint is the target temperature for the Cooling, Heating, and Auto operation modes.

13.3.1 About the setpoint

Depending on configuration, the home screen displays the temperature setpoint either as a numerical value, or as a symbol.



INFORMATION

For how to set the home screen setpoint, see the Madoka Assistant app. Also see ["Screen" \[▶ 76\]](#).

Home screen setpoint: Numerical


In case the home screen displays the temperature setpoint as a numerical value, you control the room temperature by raising or lowering the setpoint by 1°C increments.



The default setpoint range is 16°C~32°C. If any limitations are set to this range with the setpoint range function (Madoka Assistant app function; see ["Setpoint range" \[▶ 81\]](#)), it is only possible to raise or lower the setpoint up/down to the set maximum/minimum setpoint range limits.


Home screen setpoint: Symbolic

In case the home screen displays the temperature setpoint as a symbol, you control the room temperature by raising or lowering the setpoint in relation to the "reference setpoint" (visually indicated by the marker in the middle of the thermometer).



It is possible to raise the setpoint up to three steps of 1°C above and up to three steps of 1°C below the reference setpoint.

Example: if the reference setpoint is 25°C, it is possible to raise the setpoint to 28°C and lower it to 22°C.



INFORMATION

For how to set the reference setpoint, see the Madoka Assistant app. Also see "Screen" [▶ 76].


Exceptions to this logic are possible in case of:

- Setpoint range limitations
- Central control / control by a schedule

Setpoint range

If any limitations are set to the default setpoint range (16°C~32°C) with the setpoint range function (Madoka Assistant app function; see "Setpoint range" [▶ 81]), it is only possible to raise or lower the setpoint up/down to the set upper/lower setpoint range limits.



Example: if the reference temperature is 25°C, you can normally lower the setpoint three steps to 22°C. However, if a setpoint range limit is set to 23°C, you can only lower the setpoint to 23°C.



Central control / Schedule

If the system is under the control of a centralised controller or a schedule, then the regular +3°C/-3°C setpoint range limits can get overruled AND changed.

IF	THEN
The centralised controller or schedule imposes a setpoint that is within the regular +3°C/-3°C setpoint range.	Nothing unusual happens and the system follows the regular setpoint and setpoint range logic.

IF	THEN
<p>The centralised controller or schedule imposes a setpoint that exceeds the regular +3°C/−3°C setpoint range.</p>	<p>The imposed setpoint becomes the new upper/lower limit of the +3°C/−3°C range, and the whole range shifts in relation to this new limit.</p> <p>Example: the reference setpoint is set to 25°C, yielding the following setpoint range:</p>  <p>If the centralised controller or schedule changes the setpoint to 21°C, which is below the range, then "21°C" becomes the new lower limit, and the range shifts in relation to this new limit.</p> 

13.3.2 To set the setpoint

Prerequisite: The active operation mode is either 'Cooling', 'Heating', or 'Auto'.

- 1 In the home screen, use  and  to adjust the setpoint.



Result: The indoor unit changes its temperature setpoint.

13.4 Date and time

Set the date and time for the indoor units connected to the controller.

13.4.1 About date and time


Depending on daylight saving time settings, the date and time menu has the following daylight saving time indicators:

	Summer time
	Winter time


For more information, see ["Indoor unit field settings" \[▶ 57\]](#) (remote controller settings) and ["Date and time" \[▶ 78\]](#) (app settings).

13.4.2 To set date and time

- 1 Navigate to the date and time menu.



- 2 Press **+** to activate .



Result: The fields become editable.



- 3 Set the date and time. Set with **-** and **+**. Confirm with **OK**. Cycle through the menu until all fields are set correctly.

Result: You set the date and the time.



INFORMATION

Confirming the value in a field will automatically bring you to the next field. To finish making settings and leave the menu, navigate to and confirm the value in the last field.




13.5 Airflow

13.5.1 Airflow direction

The airflow direction is the direction in which the indoor unit blows its air.

About airflow direction

The following airflow directions can be set:

Direction	Screen
Fixed position. The indoor unit blows air in 1 of 5 fixed positions.	
Swing. The indoor unit alternates between the 5 positions.	
Auto. The indoor unit adjusts its airflow direction according to movement sensed by a movement sensor.	



INFORMATION

- Depending on the type of indoor unit, and/or on system layout and organisation, Auto airflow direction may not be available.
- For some types of indoor unit, you cannot set the airflow direction.

Automatic airflow control

In the following operating conditions, the airflow direction of the indoor units is controlled automatically:

- When the room temperature is higher than the controller's setpoint for Heating operation (including Auto operation).

To set the airflow direction

- 1 Navigate to the airflow direction menu.



- 2 Use  and  to adjust the airflow direction.



- 3 Press  to confirm.

Result: The indoor unit changes its airflow direction and the controller returns to the home screen.

13.5.2 Fan speed

The fan speed is the strength of the airflow coming out of the indoor unit.

About fan speed


Depending on the indoor unit, you can choose between either:

**INFORMATION**

- For mechanical protection purposes, it is possible that the indoor unit switches itself to 'Automatic fan speed' mode.
- If the fan stops operating, this does not necessarily mean system failure. The fan can stop operating at all times.
- It may take some time before changes made to fan speed settings are actually carried out.

To set the fan speed

- 1 Navigate to the fan speed menu.



- 2 Use  and  to adjust the fan speed.



- 3 Press  to confirm.

Result: The indoor unit changes its fan speed and the controller returns to the home screen.

13.6 Advanced usage

The controller only allows for basic operation. For advanced operation, use the Madoka Assistant app.

**INFORMATION**

To operate the controller with the app, you need to connect the controller to a mobile device on which the app is installed. For instructions, see "[15.2 Pairing](#)" [▶ 68].

14 Configuration

In this chapter

14.1	Installer menu.....	51
14.1.1	About the installer menu.....	51
14.1.2	Screen settings.....	52
14.1.3	Status indicator settings.....	53
14.1.4	Field settings.....	53
14.1.5	Miscellaneous settings.....	60
14.2	Software update.....	65
14.2.1	About software updates.....	65
14.2.2	Software update with app.....	65
14.2.3	Software update with updating tool.....	66

14.1 Installer menu

14.1.1 About the installer menu


In the installer menu you can make the following settings:

Category	Icon	Settings
Screen settings		Brightness
		Contrast
Status indicator settings		Intensity
Field settings		Indoor unit field settings
		Remote controller field settings
Miscellaneous settings		Group address
		Force fan ON
		Cooling/Heating masterhood
		Information

To enter the installer menu

Prerequisite: The controller displays the home screen.


- 1 Press  and keep it pressed until the information screen appears:



INFORMATION

- The presence of icons on the information screen depends on operation status. The controller may display more or less icons than are indicated here.
- The information screen always displays the current software version, regardless of operation status.

- From the information screen, press and simultaneously and keep them pressed until you enter the installer menu:




Result: You are now in the installer menu.

14.1.2 Screen settings


To set screen brightness

Prerequisite: You are in the installer menu.

- Navigate to the screen brightness menu.



- Use and to adjust screen brightness.




- Press to confirm.

Result: The screen adjusts its brightness and the controller returns to the installer menu.


To set screen contrast

Prerequisite: You are in the installer menu.

- Navigate to the screen contrast menu.



- Use and to adjust screen contrast.



- 3 Press  to confirm.


Result: The screen adjusts its contrast and the controller returns to the installer menu.

14.1.3 Status indicator settings


To set status indicator intensity

Prerequisite: You are in the installer menu.

- 1 Navigate to the status indicator intensity menu.



- 2 Use  and  to adjust status indicator intensity.




- 3 Press  to confirm.

Result: The status indicator adjusts its intensity and the controller returns to the installer menu.

14.1.4 Field settings

About field settings

The controller allows for making field settings related to the indoor unit, and to the controller itself.

Screen	Field settings
	Indoor unit
	Remote controller




In both cases, the setting procedure is the same. For instructions, see "[Setting procedure](#)" [[▶ 54](#)].




Setting procedure

Field settings are composed of the following components:

- 1 Modes ("Mode"),
- 2 Units ("Unit"),
- 3 Settings ("SW"), and
- 4 Values for those settings.

The field settings menus have 2 levels. You set modes and units in the first level, and settings and values in the second.


Level	Description
<p>First level</p> 	<p>Mode (Mode)</p>  <p>A mode is a group of settable parameters.</p> <p>In the field settings tables, find available mode numbers in the "Mode" column. Mode numbers that apply to individual indoor units are between brackets in the "Mode" column.</p> <hr/> <p>Unit (Unit) (indoor unit field settings only)</p>  <p>A unit is an individual unit to which a setting might apply.</p> <p>When making field settings for individual units, this is the place where you define the number of the unit to which the setting applies.</p> <p>When making field settings for grouped units, you do NOT set the unit number. The settings will then apply to all indoor units that are part of that group.</p>

Level	Description
Second level 	<p data-bbox="673 203 823 237">Setting (SW)</p>  <p data-bbox="673 421 1433 488">A setting is a settable parameter. These are the settings you are making.</p> <p data-bbox="673 501 1474 568">In the field settings tables, find the available setting numbers in the "SW" column.</p> <p data-bbox="673 584 746 618">Value</p>  <p data-bbox="673 801 1417 869">A value is one of a fixed set of values that you can choose for a setting.</p> <p data-bbox="673 882 1484 949">When the value field contains a "-", there are no values available for the selected setting:</p>  <p data-bbox="673 1131 1484 1232">When making group settings, you can ONLY set a value for a setting if the value field contains a "*" (if the value field does NOT contain a "*", you cannot apply the selected setting to the group):</p>  <p data-bbox="673 1413 1474 1480">In the field settings tables, find the available values for each setting in the "Value" column.</p>


Navigation

To navigate through the field settings menus, use **←**, **○**, and **+**.

- 1 Use **←** and **+** to move the highlighter.




- 2 Press **○** to select a field setting component.




- 3 Use **←** and **+** to change the value of that field setting component.


- 4 Press  to confirm that value.
- 5 In the first level, select  to move to the second level.



- 6 In the second level, navigate and select in the same way as you did in the first level.
- 7 Select  to confirm and activate made settings.



- 8 At all times, select  to go back a level.



Indoor unit field settings

The setting procedure is different depending on whether you want to make settings for individual indoor units, or for groups of indoor units.

Individual indoor units

- Define a mode by setting a Mode number (number between brackets)
- Define the unit to which the setting will apply by setting a Unit number
- Define the setting by setting a SW number
- Define a value for that setting

Groups of indoor units

- Define a mode by setting a Mode number (number NOT between brackets)
- Do NOT set a Unit number (setting applies to all the units in the group)
- Define the setting by setting a SW number
- Define a value for that setting

Mode	SW	Setting (SW) description		—					
				01	02	03	04		
10 (20)	00	Filter contamination timer: set the timer for the appearance of the "Time to clean filter" screen.	Ultra long life filter	Light	±10000 hrs	Heavy	±10000 hrs	—	—
			Long life filter		±2500 hrs		±1250 hrs		
			Standard filter		±200 hrs		±100 hrs		
	01	Long life filter: if applicable, set which type of long life filter is used.	Long life filter	—	Standard filter	—			
02	Controller thermostat sensor: set how the controller thermostat sensor is used.	Used in combination with indoor unit thermistor	Not used	Used exclusively	—				
03	Disable filter sign: set whether or not the filter sign can be displayed.	Display	Do not display	—	—				
12 (22)	02	Thermostat differential: if the system contains a remote sensor, set the increase/decrease increments.	1°C	0.5°C	—	—			
	08	External On/OFF input: set the operation of voltage free contacts T1/T2 (indoor unit contacts)	Forced OFF	On/OFF operation	Emergency	—			
13 (23)	00	High air outlet velocity: set in case of high-ceiling applications.	h≤2.7 m	2.7 m<h≤3 m	3 m<h≤3.5 m	—			
	01	Airflow direction: set in case an indoor unit is equipped with an option kit that blocks the airflow.	4-way flow	3-way flow	2-way flow	—			
1c	01	Thermostat sensor: set which thermostat sensor you want to use.	Indoor unit thermistor	Controller thermistor	—	—			
	02	Cooling/Heating icon in Auto operation mode: set whether heating and cooling icons are displayed during Auto operation.	Do not display	Display	—	—			
1e	02	Setback function: set Setback operation.	No Setback	Heating only	Cooling only	Heating and Cooling			
1B	08	Daylight saving time. Set how the system controls daylight saving time.	Disable	Automatic changeover	Manual changeover	Centralised control			



INFORMATION

- The connection of optional accessories to the indoor unit might cause changes to some field settings. For more information, see the installation manual of the optional accessory.
- For details about the specific field settings of each type of indoor unit, see the installation manual of the indoor units.
- Field settings that are not available for a connected indoor unit are not displayed.
- Field setting default values are different depending on the indoor unit model. For more information, see the service manual of the indoor units.

Remote controller field settings



INFORMATION

Remote controller field setting R1-11 allows for changes to the behaviour of the status indicator, making the controller suitable for use in hotels.

Mode	SW	SW description	Value	Default value
R1	3	Controller thermistor adjustment (Cooling)	0: -3.0°C, 1: -2.5°C, 2: -2.0°C, 3: -1.5°C, 4: -1.0°C, 5: -0.5°C, 6: ±0°C, 7: +0.5°C, 8: +1.0°C, 9: +1.5°C, 10: +2.0°C, 11: +2.5°C, 12: +3.0°C	6
	4	Controller thermistor adjustment (Heating)	0: -3.0°C, 1: -2.5°C, 2: -2.0°C, 3: -1.5°C, 4: -1.0°C, 5: -0.5°C, 6: ±0°C, 7: +0.5°C, 8: +1.0°C, 9: +1.5°C, 10: +2.0°C, 11: +2.5°C, 12: +3.0°C	6
	5	Controller thermistor adjustment (Auto)	0: -3.0°C, 1: -2.5°C, 2: -2.0°C, 3: -1.5°C, 4: -1.0°C, 5: -0.5°C, 6: ±0°C, 7: +0.5°C, 8: +1.0°C, 9: +1.5°C, 10: +2.0°C, 11: +2.5°C, 12: +3.0°C	6
	6	Controller thermistor adjustment (Fan only)	0: -3.0°C, 1: -2.5°C, 2: -2.0°C, 3: -1.5°C, 4: -1.0°C, 5: -0.5°C, 6: ±0°C, 7: +0.5°C, 8: +1.0°C, 9: +1.5°C, 10: +2.0°C, 11: +2.5°C, 12: +3.0°C	6
	7	Home screen	0: Detailed 1: Standard	1
	8	Backlight no-operation timer	0: 5 seconds 1: 10 seconds 2: 20 seconds	0
	9	Status indicator faintness	0: 0% (OFF), 1: 1%, 2: 2%, 3: 3%, 4: 5%, 5: 7%, 6: 9%, 7: 11%, 8: 13%, 9: 15%, 10: 17%, 11: 20%	9
	10	Backlight faintness	0: 0% (OFF), 1: 1%, 2: 2%, 3: 3%, 4: 4%, 5: 5%	5
	11	Status indicator mode	0: Normal 1: Hotel setting 1 2: Hotel setting 2	2
	13	Bluetooth Low Energy advertising	0: Always advertising 1: Enable manually	0


Mode	SW	SW description	Value	Default value
R2	1	Touch button indicator (on screen)	0: None 1: Small 2: Medium 3: Large	1
1E	8	Home screen setpoint	1: Numerical 2: Symbolic	1

14.1.5 Miscellaneous settings

Group address

About group address


To control the system with central control equipment, it is required that you assign the indoor units with the necessary addresses. It is possible to assign an address to a group of indoor units, or to individual indoor units.

Group of indoor units	
Individual indoor units	


To assign an address to a group of indoor units

Prerequisite: You are in the installer menu.


- 1 Navigate to the address settings menu.




- 2 Select "Group"




- 3 Confirm your selection.




- 4 Define the address.



- 5 Before you confirm the address, make sure is selected.



- 6 Confirm the address.




Result: You assigned an address to the group of indoor units.


To assign an address to an individual indoor unit

Prerequisite: You are in the installer menu.

- 1 Navigate to the address settings menu.




- 2 Select "Group(Unit)"




- 3 Define the indoor unit to which you want to assign the address.



- 4 Confirm your selection.




- 5 Define the address.



- 6 Before you confirm the address, make sure is selected.




- 7 Confirm the address.




Result: You assigned an address to the indoor unit.

To remove an address

- 1 Navigate to the address that you want to remove.
- 2 Change to .



- 3 Confirm your selection.



Result: The address gets removed.

Force fan ON


About Force fan ON

Force fan ON allows you to force fan operation of individual indoor units. In this way, you can check which indoor unit number was assigned to which indoor unit.

To force fan operation

Prerequisite: You are in the installer menu.


- 1 Navigate to the Force Fan ON menu.



- 2 Select an indoor unit number.





- 3 Select and press to force fan operation.



Result: The fan of the indoor unit that corresponds to the selected indoor unit number starts operating.

Cooling/Heating masterhood

About Cooling/Heating masterhood



- A** Heat pump system
- B** Heat recovery system
- a** Outdoor unit
- b** Indoor unit
- c** Remote controller
- d** BS unit

When multiple indoor units are connected to an outdoor unit, one of these units (or a group of indoor units, in case of group control) needs to be set as Cooling/Heating master. The other units/groups then become Cooling/Heating slaves, and are restricted in their operation by the master (e.g. one outdoor unit does not allow for one indoor unit to run in Cooling operation while another runs in Heating operation).

When an indoor unit or group of indoor units is set as Cooling/Heating master, the other indoor units automatically become its slaves. For instructions, see "[To set Cooling/Heating masterhood](#)" [[▶ 64](#)].

Status icon

Cooling/Heating masterhood corresponds to the following status icon:




The behaviour of this status icon is according to the following table:


To see information

Prerequisite: You are in the installer menu.

- 1 Navigate to the information menu.



- 2 Read out information.



- 3 Press **+** to go to the second page.



14.2 Software update

14.2.1 About software updates

It is strongly recommended that the remote controller has the latest software version. There are two ways to perform a software update.

Software update	Instructions
Madoka Assistant app	"14.2.2 Software update with app" [▶ 65]
Updating tool	"14.2.3 Software update with updating tool" [▶ 66]



INFORMATION

- When the software of a controller is out-of-date, the Madoka Assistant app will suggest a software update for that controller as soon as you try to connect it (the controller) to the app.
- Checking the current controller software version is possible from the information screen (see ["13.1.3 Information screen" \[▶ 40\]](#)) and/or from the information menu (["About the information menu" \[▶ 64\]](#)).

14.2.2 Software update with app

To update the software with the app:

- 1 Make sure that Bluetooth is activated on the remote controller ( displayed on the home screen). If not, activate Bluetooth according to the instructions set out in ["15.2.3 To make a Bluetooth connection" \[▶ 69\]](#).
- 2 In the home screen of the app, tap the tile of the remote controller of which you want to update the software, and follow the instruction from there.

**INFORMATION**

The Madoka Assistant app is available from Google Play and the App Store.

**INFORMATION**

When it is the first time you connect a remote controller to your device, app and user interface initiate a numeric comparison procedure. To successfully connect the controller to the app, follow the procedure.

After each successful connection to a mobile device, the controller automatically stores information about that mobile device, this to facilitate future reconnection. This information is called "bonding information".

When no bonding information is stored, (i.e. at first connection, or after it got manually removed), you will have to go through the numeric comparison procedure.

When bonding information is stored, you can connect the controller to the mobile device just by making the controller send out a Bluetooth signal and tapping the tile of the controller in the app. The controller will then connect to the mobile device automatically.

Bonding information gets stored automatically, and can be removed manually. Remove the bonding information from the controller when you want to update the software from another mobile device than the one the controller contains information about.

**INFORMATION**

To connect the remote controller to the mobile device with Bluetooth, and to perform a software update, it is required that you stay close to the remote controller (i.e. within Bluetooth range).


14.2.3 Software update with updating tool

To update the software with Updater

Prerequisite: PC with Updater (contact your dealer for the correct version of the software)

Prerequisite: PC USB cable EKPCAB4 or higher (includes a USB cable and additional connection cables)

- 1 Make sure that the indoor unit is powered OFF.
- 2 Connect the controller to the PC.



- a PC with Updater
- b USB cable
- c Controller PCB
- d To indoor unit

- 3** Power ON the indoor unit.
- 4** Open Updater.
- 5** In Updater, go to "Update procedure".
- 6** Type in the model name of the controller.
- 7** Select the desired update procedure.
- 8** Follow the on-screen instructions.

15 About the app

The Madoka Assistant app is a companion to the remote controller. Where the controller only allows for basic operation and configuration, the app offers advanced operation and configuration functionality.

In this chapter

15.1	Operation and configuration overview	68
15.2	Pairing	68
15.2.1	About pairing	68
15.2.2	To pair the app with a controller	69
15.2.3	To make a Bluetooth connection	69
15.2.4	To terminate the Bluetooth connection	70
15.2.5	To remove bonding information	71
15.3	User access levels	71
15.3.1	About user access levels	71
15.3.2	Basic mode	71
15.3.3	Advanced mode	72
15.3.4	Installer mode	72
15.4	Demo mode	73
15.4.1	About demo mode	73
15.4.2	To launch demo mode	73
15.4.3	To exit demo mode	74
15.5	Functions	74
15.5.1	Overview: Functions	74
15.5.2	General	76
15.5.3	Remote controller settings	76
15.5.4	Energy saving	78
15.5.5	Scheduling	78
15.5.6	Configuration and operation	80
15.5.7	Maintenance	83

15.1 Operation and configuration overview

The app continually searches for controllers to connect with. All controllers that are in range of your mobile device are listed in the home menu under Nearby Devices. You can also find a list of controllers you have recently interacted with under Recent Devices.

To operate and/or configure the system, tap the tile of the controller that is connected to the indoor units that you want to control.



INFORMATION

In installer mode, the "Recent devices" section is not shown. See "[15.3 User access levels](#)" [▶ 71] for more information.

15.2 Pairing

15.2.1 About pairing

Before you can actually connect with a controller, you have to make sure that the app and the controller are paired. Pair the app with all the controllers that you want to connect with.


15.2.2 To pair the app with a controller

Prerequisite: You are close to the controller.

- 1 In the app, tap the controller that you want to pair with.

Result: The operating system of your mobile device sends out a pairing request.

Result: The controller displays the following screen:



- 2 In the app, accept the pairing request.
- 3 On the controller, accept the pairing request by pressing .

Result: The app is paired with the controller.

**INFORMATION**

Once paired with the app, the controllers will remain bonded. It is not required to repeat this procedure each time you want to use the app, unless you delete the bonds.

15.2.3 To make a Bluetooth connection

Prerequisite: You have a mobile device on which the Madoka Assistant app is installed and running.

Prerequisite: On that mobile device, Bluetooth is turned ON.

Prerequisite: You are close to the remote controller.

- 1 From the home screen, press  to enter the main menu.



- 2 Use  and  to navigate to the Bluetooth menu.



- 3 Press  to enter the menu.



- 4 Press  to activate  and make the controller send out a Bluetooth signal.

Result:




Numeric comparison

- In the Madoka Assistant app, tap the tile of the controller of which you want to update the software.

Result: If it is the first time you make a connection, or when bonding information was removed, the operating system of your mobile device sends out a pairing request, including a numeric string.

Result: The controller displays a numeric string, for comparison with that of the pairing request.



- In the app, accept the pairing request.
- On the controller, press **■** to confirm the numeric string.

Result: The controller and the mobile device are connected via Bluetooth.


- To update the software, follow the instructions from the app.

15.2.4 To terminate the Bluetooth connection


- From the home screen, press **○** to enter the main menu.



- Use **■** and **+** to navigate to the Bluetooth menu.



- Press **○** to enter the menu.



- Press **+** to stop the remote controller from sending out a Bluetooth signal.

Result:




15.2.5 To remove bonding information




INFORMATION

Removing the bonding information makes the controller forget all previously bonded mobile devices. When removing the bonding information from a remote controller, also delete the bonding information from your mobile device's Bluetooth list. Failure to do this may result in unsuccessful future bonding.

- 1 From the home screen, press to enter the main menu.



- 2 Use and to navigate to the Bluetooth menu.



- 3 Press to enter the menu.



- 4 Press to remove the bonding information from the remote controller.

Result:



15.3 User access levels

15.3.1 About user access levels

The user access level defines which functions and settings are visible to the user of the app. A higher user access level will allow the user to make more in-depth changes to advanced operation and configuration settings. There are 3 possible user access levels that correspond to 3 possible modes:

- Basic
- Advanced
- Installer

15.3.2 Basic mode

This mode allows the user to access all necessary basic settings. This mode is recommended for regular end users. When you first install the app, this mode is enabled by default. To change to a different mode, see ["15.3.3 Advanced mode" \[▶ 72\]](#) or ["15.3.4 Installer mode" \[▶ 72\]](#).

15.3.3 Advanced mode

About advanced mode

Advanced mode allows you to make in-depth changes to more advanced operation and configuration settings. Once enabled, you will be able to see and modify settings that, when misconfigured, may harm the working of your device. It is recommended that only advanced users enable this setting. For an overview of which settings can be made in advanced mode, see "[15.5.1 Overview: Functions](#)" [▶ 74].

To activate advanced mode

Prerequisite: You are not in advanced mode.

- 1 Go to the main menu.
- 2 Tap "App Settings".
- 3 Tap "Advanced Settings".
- 4 Tap the switch to toggle on "Advanced Settings".
- 5 Confirm your selection by selecting "I understand" when asked.

Result: Advanced mode is activated. Advanced Settings are visible in the "Unit settings" menu.

To deactivate advanced mode

Prerequisite: You are in advanced mode.

- 1 Go to the main menu.
- 2 Tap "App Settings".
- 3 Tap "Advanced Settings".
- 4 Tap the switch to toggle off "Advanced Settings".

Result: Advanced mode is deactivated. Advanced Settings are no longer visible in the "Unit settings" menu.

15.3.4 Installer mode

About installer mode

In installer mode you have access to settings that are not available for regular end users or advanced users. For an overview of which settings can only be made in installer mode, see "[15.5.1 Overview: Functions](#)" [▶ 74].

To activate Installer mode

Prerequisite: You are not in installer mode.

- 1 Go to the main menu.
- 2 Tap "About".
- 3 Tap "Application version" five times.

Result: You are in the installer mode menu.

Result: Installer mode is automatically activated.

**INFORMATION**

- To continue using the app in installer mode, tap the return button.
- The duration of installer mode depends on installer mode settings. For more information, see ["To make Installer mode settings"](#) [▶ 73].
- There is a visual indication that installer mode is active, which can be disabled. For more information, see ["To make Installer mode settings"](#) [▶ 73].

To deactivate Installer mode

Prerequisite: You are in installer mode.

- 1 Go to the main menu.
- 2 Tap "Installer mode enabled".

Result: You are in the installer mode menu.

Result: Installer mode is automatically activated.

- 3 Deactivate installer mode by tapping the slider.

Result: Installer mode is deactivated.

To make Installer mode settings

- 1 Enable installer mode.

Result: You are in the installer mode menu.

- 2 Make installer mode settings.

Installer mode settings	Description
Installer mode	Enable or disable installer mode.
Temporary / Indefinite	Set the duration of installer mode. <ul style="list-style-type: none"> ▪ Temporary: installer mode active for 30 minutes. After 30 minutes, installer mode will automatically deactivate. (default) ▪ Indefinite: installer mode active until the next manual deactivation.
Installer mode indicator	Set whether installer mode activation is indicated by the installer mode indicator.

**INFORMATION**

Mind that installer mode is automatically enabled as soon as you enter the installer mode menu.

15.4 Demo mode

15.4.1 About demo mode

To try out the app's operation and configuration functions in a safe environment, it is possible to launch a demo version of the app.

15.4.2 To launch demo mode

Prerequisite: You are not in demo mode.

- 1 Go to the main menu.
- 2 Tap "Demo mode".

Result: You are in demo mode.

15.4.3 To exit demo mode

Prerequisite: You are in demo mode.

- 1 Go to the main menu.
- 2 Tap "Exit demo mode".

Result: You exited demo mode.

15.5 Functions

15.5.1 Overview: Functions



NOTICE

Depending on the user access level, more or less settings may be visible in the unit settings menu. See "[15.3 User access levels](#)" [▶ 71] for more information about changing modes.



INFORMATION

Settings can be saved as favourites by tapping the star symbol in the top-right corner in the menu of a specific setting. These settings are then displayed at the top of the unit settings menu, making them more easily accessible.

Category	Control
Operation	Turn ON/OFF unit operation
	Read out temperature sensor information
	Change the operation mode
	Change the setpoint
	Change the fan speed
	Change the airflow direction
	See notifications

Category	Control
Configuration and advanced operation	Make controller and indoor unit settings: General <ul style="list-style-type: none"> ▪ Firmware update ▪ Notifications Remote controller settings <ul style="list-style-type: none"> ▪ Master/slave status^(a) ▪ Screen^(a) <ul style="list-style-type: none"> - Home screen setpoint: Numerical or Symbolic ▪ Status indicator^(a) ▪ Date and time^(a) ▪ About ▪ Remove bonding information^(a) Energy saving <ul style="list-style-type: none"> ▪ OFF timer^(a) ▪ Setpoint auto reset^(a) <p style="text-align: right;">>> to be continued</p>
Category	Control
<< continuation Configuration and advanced operation	Scheduling <ul style="list-style-type: none"> ▪ Schedule ▪ Holiday Configuration and operation <ul style="list-style-type: none"> ▪ Setback^(a) ▪ Setpoint range^(a) ▪ Cooling/Heating masterhood^(a) ▪ Function lock^(a) Maintenance <ul style="list-style-type: none"> ▪ Errors and warnings^(b) ▪ Unit number^(b) ▪ Filter notifications^(a) ▪ Contact information ▪ Group address^(b) ▪ Field settings^(b) ▪ Test operation^(b) ▪ Unit status^(b) ▪ Operating hours^(b)

^(a) Available in advanced or installer mode only. For more information, see "[15.3.3 Advanced mode](#)" [▶ 72] and "[15.3.4 Installer mode](#)" [▶ 72].

^(b) Available in installer mode only. For more information, see "[15.3.4 Installer mode](#)" [▶ 72].

15.5.2 General

Remote controller firmware update

Update remote controller firmware. It is required to keep remote controller firmware up to date. When new firmware is available for a controller, the app will send out a notification in the operation screen of that controller.

To update remote controller firmware

Prerequisite: You are in the operation screen of one of the controllers, and the app notified you that new firmware for that controller is available.

Prerequisite: You are close to the controller.

- 1 Tap the settings icon.

Result: You are in the "Unit settings" menu.


- 2 At the very top, tap "Firmware update available".

Result: You are in the "Firmware update" menu.

- 3 Tap "Update firmware".

Result: The latest firmware is downloaded to the controller.

Result: During the download, the controller displays the following screen.



Result: After the download, the controller restarts to implement changes.

Notifications

Get an overview of active system notifications. These can be:

- Errors
- Warnings
- System information

15.5.3 Remote controller settings

Master/slave status

Find out if the controller you are operating is a master or a slave controller. It is not possible to make changes to master/slave status from the app. For instructions on how to change a controller's master/slave status, see "[11 Starting up the system](#)" [▶ 34].

Screen

Make remote controller screen settings:

Setting	Description
Home screen mode	Set the home screen mode: <ul style="list-style-type: none"> Standard: limited information about system operation (few status icons). Detailed: extensive information about system operation through status icons.
Home screen setpoint	Set how the home screen displays the setpoint: <ul style="list-style-type: none"> Numerical: by way of a numerical value. Symbolic: by way of a symbol. In case "Home screen setpoint " is set to "Symbolic", set the reference setpoints for both Cooling and Heating operation: <ul style="list-style-type: none"> Cooling reference setpoint Heating reference setpoint For more information, see " Home screen setpoint: Symbolic " [▶ 45].
Brightness	Set screen brightness.
Contrast	Set screen contrast.

**INFORMATION**

When making remote controller screen settings from the app, it is possible that the remote controller does not implement changes immediately. To make the controller implement changes: on the controller, navigate to the installer menu, and then back to the home screen. For instructions on how to enter the installer menu, see "[To enter the installer menu](#)" [▶ 51].

**INFORMATION**

The remote controller does NOT display negative indoor temperature values. When the indoor temperature is below 0°C, then the remote controller displays 0°C instead. In this case, the Madoka Assistant app also does not display any indoor temperature value.

Status indicator

Make remote controller status indicator settings:

Settings	Description
Mode	Check the active status indicator mode. It is not possible to set the status indicator mode from the app; this happens through remote controller field setting R1-11. For more information, see " Remote controller field settings " [▶ 58].
Intensity	Set status indicator intensity.

Date and time

Set the remote controller date and time. In the date and time menu you send date and time information to the remote controller from the app. You can choose to either send the date and time information of your mobile device ("Synchronise with device date and time"), or to manually create and send date and time information.



INFORMATION

If the controller is disconnected from the power for more than 48 hours, the date and the time need to be set again.



INFORMATION

The clock will maintain accuracy to within 30 seconds/month.

About

Read out the current remote controller and remote controller Bluetooth module software version.

Remove bonding information

Make the controller forget all previously bonded mobile devices.

15.5.4 Energy saving

OFF timer

Set a timer for the system to turn OFF automatically. The timer can be enabled or disabled. When the timer is enabled, it starts running each time the system gets turned ON.

The timer has a range of 30~180 minutes, and can be set in increments of 30 minutes.

Setpoint auto reset

Set a timer for the system to automatically adjust the temperature to a set temperature value. The timer can be enabled or disabled for Heating and Cooling operation separately. When a timer is enabled, it starts running each time the system gets turned ON. When the timer runs out, the temperature setpoint will always change to the set value, also if the temperature setpoint has been changed in the meanwhile.

The timer has a range of 30~120 minutes, and can be set in increments of 30 minutes.



INFORMATION

This function cannot be used when the indoor units are controlled by a centralised controller.

15.5.5 Scheduling

Schedule

Organise system actions into schedules. The schedule function allows you to set up to 5 timed actions for each day of the week. It is possible to create up to 3 different schedules, though only 1 schedule can be active at the same time.

The action logic is as follows:

- 1 Set a timespan for the action.
- 2 Choose to turn system operation ON or OFF, and set the conditions.

IF "Operation"	THEN
ON	Set action-specific temperature setpoints for Cooling and/or Heating operation, or choose to maintain the current setpoints.
OFF	Set action-specific Setback setpoints for Cooling and/or Heating setback operation, or choose to maintain the current setpoints. For more information, see "Setback" [▶ 80]. Note: when adding or editing schedule actions, the Setback setpoints for Cooling and/or Heating can be modified. However, the Setback setpoints will only be taken into account if Setback operation is enabled. Modifying the Setback setpoints from the Add action screen does NOT enable Setback operation automatically.



INFORMATION

If the "Home screen setpoint" setting is set to "Symbolic", there is only a limited range of possible temperature setpoints. However, if "Home screen setpoint" is set to "Symbolic", and there is a setpoint change coming from a schedule, then the system will disregard the regular setpoint limitations and allow the schedule to exceed the limited setpoint range. For more information, see ["Home screen setpoint: Symbolic"](#) [▶ 45].



INFORMATION

This function cannot be used when the indoor units are controlled by a centralised controller.



INFORMATION

This function cannot be used when digital input adapter BRP7A5* is part of the system.

Holiday

Select days of the week for which the schedule does not apply. On the selected days, any actions set with the schedule function do not get executed. The holiday function can be enabled or disabled. When enabled, it applies to any schedule that is set to be active.



INFORMATION

For more information, see ["Schedule"](#) [▶ 78].

15.5.6 Configuration and operation


Setpoint logic

The setpoint logic is executed by the indoor unit.

Setback

Enable Setback temperature control. Setback is a function that keeps the room temperature in a specific range when the system is turned off (by the user, the schedule function, or the OFF timer). To achieve this, the system temporarily runs in Heating or Cooling operation mode, according to the setback setpoint and recovery differential.

Example:



Settings			Result
Heating operation 	Heating setback setpoint	10°C	If the room temperature drops below 10°C, the system automatically starts heating operation. If after 30 minutes the temperature rises above 12°C, the system stops heating operation, and turns off again. When the room temperature drops below 10°C again, the process gets repeated.
	Heating recovery differential	+2°	
Cooling operation 	Cooling setback setpoint	35°C	If the room temperature rises above 35°C, the system automatically starts cooling operation. If after 30 minutes the temperature drops below 33°C, the system stops cooling operation, and turns off again. When the room temperature rises above 35°C again, the process gets repeated.
	Cooling recovery differential	-2°C	



INFORMATION

- Setback is by default enabled.
- Setback turns on the system for at least 30 minutes, unless the setback setpoint is changed, or the system is turned on with the ON/OFF button.
- When Setback is active, you cannot make changes to fan speed settings.
- When Setback activates while the system is set to Auto operation mode, the system will switch to Cooling or Heating operation mode, depending on which is required. The Setback setpoint displayed on the operation screen is then according to the operation mode.
- When Setback is active and the "Home screen setpoint" setting is set to "Symbolic", then there is no indication of Setback operation on the remote controller home screen.

**INFORMATION**

This function cannot be used when the indoor units are controlled by a centralised controller.

**INFORMATION**

The default setpoint range limits for Setback operation are [33°C-37°C] for Cooling operation, and [10°C-15°C] for Heating operation. It is not possible to change these limits.

Setpoint range

Set a limitation to the temperature setpoint range of both Cooling and Heating operation.

**INFORMATION**

This function cannot be used when the indoor units are controlled by a centralised controller.

**INFORMATION**

The default setpoint range limits for both Heating and Cooling operation is [16°C-32°C], regardless of whether or not "Setpoint range limitation" is enabled. It is not possible to exceed these limits.

Cooling/Heating masterhood

Set an indoor unit (or group of indoor units) as Cooling/Heating master. When multiple indoor units are connected to an outdoor unit, one of these units (or a group of indoor units, in case of group control) needs to be set as Cooling/Heating master. The other units/groups then become Cooling/Heating slaves, and are restricted in their operation by the master (e.g. one outdoor unit does not allow for one indoor unit to run in Cooling operation while another runs in Heating operation).

When an indoor unit or group of indoor units is set as Cooling/Heating master, the other units/groups automatically become its slaves. To turn a slave unit into the master, first connect the app to the controller controlling the currently active master and release it from its masterhood, then set the (slave) unit as master.

Function lock

Make functions and operation modes unavailable by locking them, or release a function lock if it is no longer required. It is possible to lock the following functions and operation modes:

Remote controller	▪ Menu button
-------------------	---------------



Functions	<ul style="list-style-type: none"> ▪ Setpoint ▪ Fan speed ▪ Operation mode (locked by default) ▪ Airflow direction ▪ System ON/OFF ▪ Setpoint range ▪ Setback ▪ Setpoint adjustment timer ▪ OFF timer ▪ Schedule ▪ Date and time
Operation modes	<ul style="list-style-type: none"> ▪ Automatic ▪ Cooling ▪ Heating ▪ Fan

i **INFORMATION**

- When you lock an operation mode that is active at the moment of locking, that mode will still be active upon saving settings and leaving the menu. Only when you change the operation mode, that mode will not be available anymore.
- When you lock ALL operation modes, it will not be possible to switch to an operation mode other than the one that is active at the moment of locking.

Remote controller

Locking functions and operation modes from the app results in changes on the remote controller.

Operation	Remote controller
Home screen	<p>When you lock functions/buttons that are operated from the controller home screen, the controller will display a lock screen when you try to use these functions/buttons.</p> 
Main menu	<p>When you lock functions that are main menu items on the controller, these functions get crossed out in the main menu, and accompanied by a lock icon.</p>  <p>When locking operation modes, the controller simply omits them from the operation mode menu.</p>

15.5.7 Maintenance

Errors and warnings

Consult the error history, and temporarily enable/disable the pushing of error and/or warning notifications.

The pushing of error and warning notifications is by default enabled. Disable "Display errors" and "Display warnings" to prevent the system from pushing error and warning notifications for 48 hours. After 48 hours, "Display errors" and "Display warnings" become automatically enabled again.

Unit number

Change the unit number of the indoor unit(s). To configure individual indoor units, these units require a unit number. The unit number of an indoor unit is its ranking in the list. To give a unit a new unit number, change its ranking by either moving it to an empty slot, or switching it with another indoor unit. If you need help identifying physical indoor units, tap an indoor unit's fan icon to make that indoor unit's fan operate.

Group address

Assign addresses to the indoor units, this to control the system with central control equipment. You can assign an address to the group of indoor units connected to the controller, and to indoor units individually.

Filter notifications

Dismiss notification

The app displays a notification in the operation screen when it is time to perform one of the following filter-related maintenance activities:

- Replacement of indoor unit filter.
- Cleaning of indoor unit filter.
- Cleaning of indoor unit element.

Perform the required maintenance, then dismiss the notification.



INFORMATION

For more information on indoor unit maintenance, see the operation manual of the indoor unit.

Reset notification timer

Filter maintenance due time is controlled by timers. The app sends out a maintenance notification each time a timer expires. It is possible to reset these timers.



INFORMATION

To use this function, it is required that you use the app in installer mode. For instructions on how to activate installer mode, see "[15.3.4 Installer mode](#)" [▶ 72].

Contact information

Enter the phone number of the system's service contact.

Field settings

Make indoor unit and remote controller field settings. For an overview of possible field settings, see "[Indoor unit field settings](#)" [▶ 57] and "[Remote controller field settings](#)" [▶ 58].

Setting procedure

Field settings are composed of the following components:

- Modes
- Units
- Settings
- Values

The field settings procedure differs depending on whether you are making settings for individual indoor units or for groups of indoor units, or for the remote controller.

Field settings type	Procedure
Individual indoor units	<ul style="list-style-type: none"> ▪ Set the field setting type to "Indoor unit". ▪ Define a mode. In the field settings table, find this number between brackets in the Mode column. ▪ Define the unit to which the setting will apply by setting a unit number. ▪ Define the setting by tapping the right tile in the app. In the field settings table, find settings in the SW column. ▪ Define a value for that setting.
Groups of indoor units	<ul style="list-style-type: none"> ▪ Set the field setting type to "Indoor unit". ▪ Define a mode. In the field settings table, find this number NOT between brackets in the Mode column. ▪ Do NOT set a unit number (the settings will apply to all units in the group). ▪ Define the setting by tapping the right tile in the app. In the field settings table, find settings in the SW column. ▪ Define a value for that setting.
Remote controller	<ul style="list-style-type: none"> ▪ Set the field setting type to "Remote controller". ▪ Define a mode. ▪ Define the setting by tapping the right tile in the app. In the field settings table, find settings in the SW column. ▪ Define a value for that setting.

Default values

Field setting default values are different depending on the indoor unit model. For more information, see the service manual of the indoor units. For the following field settings, the default values are the same for all indoor unit models:

Field setting	Default value
Thermostat sensor	02
Setback	04
Remote controller thermostat sensor	02



INFORMATION

- The connection of optional accessories to the indoor unit might cause changes to some field settings. For more information, see the installation manual of the optional accessory.
- For details about the specific field settings of each type of indoor unit, see the installation manual of the indoor units.
- Outdoor unit field settings can only be configured via the outdoor unit PCB. For more information, see the installation manual of the outdoor unit.
- Field settings that are not available for a connected indoor unit are not displayed.

Test operation

Perform an indoor unit test operation. During the test run, the indoor units cycle through various operation modes and functions to check if they are ready for operation.

When

Only activate the test operation after the following is completed:

- Installation of refrigerant piping;
- Installation of drain piping;
- Connection of electrical wiring.

Typical workflow

Performing a test operation typically consists of the following stages:

- 1 Activating the test operation (Madoka Assistant app),
- 2 Testing the indoor unit functions according to the instructions set out in "[To perform a test operation](#)" [[▶ 86](#)],
- 3 Deactivating the test operation (Madoka Assistant app),
- 4 Checking the error history for possible errors.
- 5 If applicable, fixing the causes of those errors.
- 6 Repeating the procedure if required.



INFORMATION

This function is only available for Sky Air indoor units.



INFORMATION

Also see the installation manual of the indoor unit and outdoor unit.

Precautions when performing a test operation



CAUTION

Before starting up the system, make sure:

- The indoor and outdoor unit wiring is completed.
- The switch box covers of the indoor and outdoor units are closed.



NOTICE

Turn ON the power 6 hours before operation in order to have power running to the crankcase heater and to protect the compressor.



INFORMATION

After the installation of the refrigerant piping, drain piping, and electrical wiring, make sure to clean the inside of the indoor unit, as well as the decoration panel.

To perform a test operation

- 1 Confirm that the indoor unit gas and liquid stop valves are open.



INFORMATION

It is possible that the pressure inside the refrigerant circuit does not rise, despite the opened stop valve. This can be due to the expansion valve (or the like) blocking the refrigerant, and does not obstruct the test run.

- 2 Open the Madoka Assistant app.
- 3 Navigate to the operation screen of the controller that is connected to the indoor unit(s) on which you want to perform a test run.
- 4 In the operation screen, set the operation mode to Cooling.
- 5 Go to Unit settings by tapping the cogwheel in the upper right corner of the operation screen.

Result: You are in the Unit settings menu.
- 6 Scroll down to the Maintenance section and tap Test operation.

Result: You are in the Test operation menu.
- 7 Tap Start test operation.

Result: The indoor unit(s) enter test operation mode, during which normal operation is not possible.
- 8 Return to the operation screen.
- 9 Tap Vertical airflow direction.
- 10 Tap Fixed.
- 11 Cycle through the five fixed airflow directions, and confirm if the indoor unit flaps behave correspondingly.
- 12 Return to the Test operation menu.
- 13 Tap Stop test operation.

Result: The indoor units leave test operation mode. Normal operation is possible again.
- 14 Go to "[13 Operation](#)" [[▶ 39](#)] and confirm if the indoor unit(s) behave according to the information set out there.

- 15 Check the error history. If required, solve the cause of the errors and perform the test operation again.

**INFORMATION**

The test operation finishes after 30 minutes.

Unit status

With Unit status, you can:

- Information retrieval: enter a code to make the system retrieve specific information about an indoor or outdoor unit component. First select a unit by way of its unit number, then enter the code to start the information retrieval.
- Indoor unit: see information provided by various sensors that are present in the system. First select a unit by way of its unit number.

**INFORMATION**

The **information retrieval** function is only present in the menu when you use the app in installer mode. For instructions on how to activate installer mode, see "[15.3.4 Installer mode](#)" [▶ 72].

Operating hours

Monitor indoor and outdoor unit operating hours.

16 Maintenance

In this chapter

16.1	Maintenance safety precautions.....	88
16.2	About maintenance	88
16.3	To remove a warning screen	90
16.4	To clean the controller	90
16.5	Time to clean filter indication	90
16.5.1	To remove the Time to clean filter indication	90

16.1 Maintenance safety precautions



WARNING

Before carrying out any maintenance or repair activities, stop system operation with the controller, and turn off the power supply circuit breaker. **Possible consequence:** electrical shock or injury.



NOTICE

To clean the controller, do NOT use organic solvents, such as paint thinner. **Possible consequence:** damage, electrical shock, or fire.



WARNING

Do NOT wash the remote controller. **Possible consequence:** electric leakage, electrical shock, or fire.





INFORMATION

When the dirt on the surface cannot be removed easily while cleaning the controller, soak the cloth in neutral detergent diluted with water, squeeze the cloth tightly, and clean the surface. Afterwards, wipe dry with a dry cloth.

16.2 About maintenance

When an indoor unit component needs maintenance, the controller displays  on the home screen, and generates a warning screen. Go to the warning screen to see which component needs maintenance, perform the maintenance, and remove the warning screen.

The following warning screens are related to indoor unit maintenance:

<p>Clean the indoor unit filter</p> 	<p>Replace the indoor unit filter</p> 
<p>Empty the indoor unit dustbox</p> 	<p>—</p>

The procedure to see the warning screen is different depending on the set status indicator mode (i.e. "Normal", "Hotel 1", or "Hotel 2").



INFORMATION

By default, the controller is in status indicator mode "Hotel 2".

Status indicator mode: "Normal"

Prerequisite: The controller displays the home screen, and  is visible, indicating maintenance.

- 1 Press .

Result: The controller displays the warning screen.



Status indicator mode: "Hotel 1" and "Hotel 2"

Prerequisite: The controller displays the home screen, and  is visible, indicating maintenance.


- 2 Press  and keep it pressed.

Result: The controller displays the information screen.



- 3 Press  and keep it pressed.

Result: The controller displays the warning screen.



16.3 To remove a warning screen

Prerequisite: The controller displays the home screen, and  is visible, indicating maintenance.

- 1 Go to the warning screen.



- 2 Solve the cause of the warning screen.
- 3 Press  to remove the warning screen.

Result: The controller returns to the home screen. If the cause of the warning was properly solved,  has disappeared.



INFORMATION

The procedure to see the warning screen is different depending on the set status indicator mode (i.e. "Normal", "Hotel 1", or "Hotel 2"). For more information, see ["16.2 About maintenance" \[▶88\]](#).

16.4 To clean the controller


- 1 Wipe the screen and other surface parts of the controller with a dry cloth.

16.5 Time to clean filter indication

When the indoor unit filter is dirty and needs to be cleaned, the controller will indicate this by displaying  in the top left corner of the home screen, and confronting you with the 'Time to clean filter' screen as soon as you try to enter the main menu from the home screen.

16.5.1 To remove the Time to clean filter indication

Prerequisite: On trying to enter the main menu from the home screen, you are confronted with the 'Time to clean filter' screen.



- 1 Clean the filter.
- 2 Press  to remove the 'Time to clean filter' indication.

17 Troubleshooting

17.1 Error codes of the indoor unit

When the system is in error, the controller displays  on the home screen, and generates an error screen. Go to the error screen to see the error code, solve the cause of the error, and press  to remove the error screen. For a list of error codes and their meaning, see the documentation of the indoor unit.

The procedure to see the error screen is different depending on the set status indicator mode (i.e. "Normal", "Hotel 1", or "Hotel 2").



INFORMATION


By default, the controller is in status indicator mode "Hotel 2".

Status indicator mode: "Normal"

Prerequisite: The controller displays the home screen, and  is visible, indicating error.

- 1 Press .

Result: The controller displays the error screen.




Status indicator mode: "Hotel 1" and "Hotel 2"

Prerequisite: The controller displays the home screen, and  is visible, indicating error.


- 2 Press  and keep it pressed.

Result: The controller displays the information screen.



- 3 Press  and keep it pressed.

Result: The controller displays the error screen.




18 Technical data


A **subset** of the latest technical data is available on the regional Daikin website (publicly accessible). The **full set** of the latest technical data is available on the Daikin Business Portal (authentication required).

18.1 Connection diagram


18.1.1 Typical layout



18.1.2 Typical layout for group control



18.1.3 Controller + DIII central control equipment



19 Glossary

DHW = Domestic hot water

Hot water used, in any type of building, for domestic purposes.

Dealer

Sales distributor for the product.

Authorised installer

Technical skilled person who is qualified to install the product.

User

Person who is owner of the product and/or operates the product.

Applicable legislation

All international, European, national and local directives, laws, regulations and/or codes that are relevant and applicable for a certain product or domain.

Service company

Qualified company which can perform or coordinate the required service to the product.

Installation manual

Instruction manual specified for a certain product or application, explaining how to install, configure and maintain it.

Operation manual

Instruction manual specified for a certain product or application, explaining how to operate it.

Accessories



Labels, manuals, information sheets and equipment that are delivered with the product and that need to be installed according to the instructions in the accompanying documentation.

Optional equipment

Equipment made or approved by Daikin that can be combined with the product according to the instructions in the accompanying documentation.

Field supply

Equipment NOT made by Daikin that can be combined with the product according to the instructions in the accompanying documentation.



ERC